



RacingLine Front Endlinks 02+ Altima/04+ Maxima

Included items

- 2x Black turnbuckle
- 2 x Ball joints
- 2x rod ends
- 2x washers
- 2x 12 mm bolts
- 2x 12mm reg. nuts
- 4x 12mm serrated nuts

Tools needed (application may vary slightly)

- 19mm wrench
- 19mm sockets
- Ratchet

1. Raise both side of the front end of vehicle and remove wheels to get to endlinks.
2. Remove the stock endlink using the 19mm ratchet on the nut and the 19mm wrench on the reverse side to stop the internal ball joint from spinning



3. Install endlinks ball joint side up as shown.

***Note** for 02-06 altima and 04-08 Maximas using OEM struts, install second nut on to ball joint as shown below to allow for adequate spacing.



**



4. Install lower portion to sway bar as illustrated, with bushings surrounding the rod end.

